

BEADED LINER INSTALL TIPS

- Check liner box and inspect for any damage prior to opening box.
- Double check the liner size on the box and confirm it is the right size.
- Temperature can play a big part in the liner installation process. Try to install the liner on a sunny day with outside temperatures at least 60 degrees or more.
- To help minimize any liner wrinkles, dish out the pool floor approx. 2" below the pool wall bottom rails towards the middle of the pool. This will allow the liner to stretch and minimize the chance of liner wrinkles.
- Avoid putting too much sand inside the pool floor area, this can cause liner wrinkles.
- Manufactured preformed pool cove is the preferred cove for above ground pools. It helps speed up the installation process and will help insure the liner is protected from the pool wall frame. **DO NOT USE SAND AS A COVE.** Sand will wash out and leave a void for the liner to be exposed and cause damage.
- A solution of dishwashing liquid and water placed in a hand spray bottle can be helpful when installing the liner bead into the bead receiver. Spray the solution into the bead receiver track as you install the liner bead. This will also help if you need to adjust the liner bead to finish the liner installation. Just a couple of drops of dishwashing liquid in the spray bottle should be enough.
- When filling the pool, do not fill the pool too fast if the temperatures are below 60 degrees and no sun. The liner needs time to expand during the fill process or pool wall and/or liner damage could occur.